

Instructions for Use Pre-Op Gloves (5177M1 & 5177M2)



1) Insert either your right or left hand into the opening of the Pre-op Glove.



2) Turn your hand over and remove the paper backing from the top and bottom of palm area on the Glove to expose the adhesive.



3) The entire palm area is now ready to pick up any loose hair or foreign matter on the patient or surrounding prep area.



4) Gently pat the Pre-op Glove over the shaved or prepped area until all loose matter has adhered to the glove. Dispose of glove.