

INSTRUCTIONS FOR

The IV Lock Boxes(2505M12-M15)



Step 1. Open the pod and loosen the locking wheel on the inside of the box.



Step 3. Tighten the locking wheel on the inside of the pod. Once tightened the POD cannot be removed from the pole without opening the box.



Step 2. Turn the mounting knob to make room for the pole. Mount the pod to the IV pole and tighten the mounting knob.

