

Clear Tip Out Bin Rails

Provide an easy and efficient way to build a high density expandable storage system. U-channel shaped rails allow Tip Out Bins to slide easily to any height. Each Tip Out Bin needs 2 disks and 2 screws (7472M9) in order to affix to all rails and frames. (Bins are sold separately). Powder coat finish.

Available in: Black

7473M1 7473M2 7473M3

MODEL NO.	DESCRIPTION	CTN QTY	CTN WGT	NO. OF BINS TO FIT EACH FRAME					
				2600M1	2600M2	2600M3	2600M4	2600M5	2600M6
7473M1	Two 24"H Rails	1 Set	2 lbs	1	2	3	3	5	8
7473M2	Two 48"H Rails	1 Set	4 lbs	3	5	6	7	10	16
7473M3	Two 70"H Rails	1 Set	5 lbs	5	7	8	10	15	23



Utilize rails when base of the first bin will sit on the floor



7472M9
Disk and Screw
(Sold separately)

TIP OUT
BIN



Utilize frame when bins will be mounted above floor level

Clear Tip Out Bin Frames

F frames are manufactured with preset parallel distance allowing Tip Out Bins to be stacked and removed easily and efficiently. All frames have a ledge at the bottom allowing Tip Out Bins to be secured above ground level. Each Tip Out Bin needs 2 disks and 2 screws (7472M9) in order to affix to all rails and frames. (Bins are sold separately). Powder coat finish.

Available in: Black

7472M1 7472M2 7472M3

MODEL NO.	DESCRIPTION	CTN QTY	CTN WGT	NO. OF BINS TO FIT EACH FRAME					
				2600M1	2600M2	2600M3	2600M4	2600M5	2600M6
7472M1	24"H Frame	1	3 lbs	1	2	3	3	5	8
7472M2	48"H Frame	1	5 lbs	3	5	6	7	10	16
7472M3	70"H Frame	1	7 lbs	5	7	8	10	15	23

HOW TIP OUT BINS AFFIX TO RAILS AND FRAMES



- 1 Having removed transparent clear cups, insert screw corresponding to screw holes in Tip Out Bin housing.



- 2 Insert screws and screw into disk on back of Tip Out Bin housing.



- 3 Insert disk into frame rails.



- 4 Once in place, tighten screws to affix Tip Out Bin to frame rails.